
# VERSA-TOGGLE

# SELF-DRILLING WALLBOARD



## **AVAILABLE MATERIALS**

- · Zinc diecast alloy
- High strength nylon

#### CONCERNS

Hollow wall anchoring only

#### FEATURES/ADVANTAGES

- Works in any wallboard thickness
- Can be easily backed out
- Low profile head
- Fast, easy installation
- Zinc Anchor can be set with a 1/4" hex bit tip


## ORDER DETAIL

|  | 1/2" Drywall  |             |                                 |         |       |             |                |  |
|--|---------------|-------------|---------------------------------|---------|-------|-------------|----------------|--|
|  | Order<br>Code | Description | Maximum<br>Fixture<br>Thickness | Tension | Shear | Box<br>Qty. | Master<br>Qty. |  |
|  | 8561000       | Plastic     | 3/4"                            | 81      | 150   | 100         | 1200           |  |
| *  | 8561100       | Plastic Kit | 3/4"                            | 81      | 150   | 1           | 12             |  |
|  | 8571000       | Zinc        | 3/4"                            | 90      | 150   | 100         | 1200           |  |
| *  | 8571100       | Zinc Kit    | 3/4"                            | 90      | 150   | 1           | 12             |  |
| *Includes 50 #8 x 1-1/4" Screws and 50 Anchors |               |             |                                 |         |       |             |                |  |

Includes 50 #8 x 1-1/4" Screws and 50 Anchors

# INSTALLATION

- 1 Place driving tool in anchor and puncture wallboard with anchor point.
- 2 Screw anchor clockwise applying forward pressure until head is flush to wall.
- 3 Place fixture over hole and tighten #8 or #10 sheet metal screw.



## **AVAILABLE MATERIALS**

• High strength nylon

#### FEATURES/ADVANTAGES

- Excellent for light loads in gypsum board
- Fast, easy installation

#### APPROVALS/LISTINGS

• G.S.A. Spec FF-B-588D, Type IV

## ORDER DETAIL

|  | Order<br>Code | Size  | Hole<br>Diameter | Wall<br>Thickness | Screw<br>Size | Box<br>Qty. | Master<br>Qty. |
|--|---------------|-------|------------------|-------------------|---------------|-------------|----------------|
|  | 8512000       | Short | 5/16"            | 1/2"              | 6-8           | 100         | 800            |
|  | 8578000       | Long  | 5/16"            | 1"                | 8-12          | 100         | 800            |

# INSTALLATION

- 1 Drill 5/16" dia. hole, squeeze toggle wings flat and push into hole.
- 2 Tap flush with wall.
- 3 Put fixture in place, insert screw and tighten until secure.

